



An Online Neutron Detection System for Electron Storage Rings



P.K. Job
Radiation Physicist
Advanced Photon Source
Argonne National Laboratory



An Online Neutron Detection System for Electron Storage Rings

- Neutron Damage to Storage Ring Components
- Beam Loss and Neutron Production
- Fission Detectors: A Unique Advantage
- Calibration of the Fission Detectors
- Results and Discussion




An Online Neutron Detection System for Electron Storage Rings



Insertion Device Cumulative Dose Results

Cumulative Insertion Device Dose

Run 1996-6 through Run 2002-3




An Online Neutron Detection System for Electron Storage Rings



Pioneering
Science and
Technology


Results of Sample Magnet Irradiation



An Online Neutron Detection System for Electron Storage Rings




Electromagnetic Shower



Electromagnetic Shower in Pb (EGS4 Simulation)

SSC CALORIMETER 1

11/04/90



Photon Cross Sections for C and Pb

Contributions to Photon Cross Section in Carbon and Lead




Figure 11.3: Photon total cross sections as a function of energy in carbon and lead, showing the contributions of different processes.

- $\sigma_{p.e.}$ = Atomic photo-effect (electron ejection, photon absorption)
- $\sigma_{coherent}$ = Coherent scattering (Rayleigh scattering—atom neither ionized nor excited)
- $\sigma_{incoherent}$ = Incoherent scattering (Compton scattering off an electron)
- κ_n = Pair production, nuclear field
- κ_e = Pair production, electron field
- σ_{nuc} = Photonuclear absorption (nuclear absorption, usually followed by emission of a neutron or other particle)

From Hubbell, Gimm, and Øverbø, J. Phys. Chem. Ref. Data 9, 1023 (80). The photon total cross section is assumed approximately flat at least two decades beyond the energy range shown. Figures courtesy J.H. Hubbell.




An Online Neutron Detection System for Electron Storage Rings



Pioneering
Science and
Technology


Photoneutron Production Cross Section in Al



An Online Neutron Detection System for Electron Storage Rings




Photoneutron Spectra by 45 MeV Electrons from Target Materials



Photoneutron Production as a Function of the Stored Beam Loss on a Copper Target

Photoneutron Production due to Stored Beam Loss




An Online Neutron Detection System for Electron Storage Rings



Photoneutron Production as a Function of the TopUp Mode Injection Beam Loss


Photoneutron Production due to Top Up Mode Injection Loss




An Online Neutron Detection System for Electron Storage Rings



Schematic Diagram of the Fission Detector



Typical Neutron-Induced Fission Reaction



Fission Cross Section of Uranium Isotopes (^{235}U and ^{238}U)

Particle / Radiation	Energy	Cross Section (barns)	
		^{235}U	^{238}U
Thermal Neutrons	~25 meV	582 b	0.0 b
Fast Neutrons	~1-2 MeV	1.2 b	0.6 b
Photons	>5.3 MeV	3-30 mb	3-30 mb




An Online Neutron Detection System for Electron Storage Rings




Pioneering
Science and
Technology

Beam Loss Scenario in the Insertion Device Straight Sections



Neutron Detector Placement Inside the APS Storage Ring



Calibration of the Fission Detector with ^{252}Cf Neutron Source Spectrum


- Measure count-to-flux conversion factors for the detector-moderator configuration
- Optimize the moderator thickness to maximize detector efficiency



An Online Neutron Detection System for Electron Storage Rings




Neutron Count Rate vs. Lifetime



An Online Neutron Detection System for Electron Storage Rings



Neutron Count Rate vs. Operating Mode



An Online Neutron Detection System for Electron Storage Rings



Storage Ring Lifetime vs. Neutron Flux

Lifetime (h)	Emittance	TopUp	Neutron (cpm)	Neutron Flux (n/cm ² /s)
10.5	High	No	827	1.1E+04
10.8	Low	Yes	881	1.2E+04
13.5	High	No	597	8.0E+03
18	High	No	527	7.1E+03
21	High	No	278	3.7E+03
22	High	No	166	2.2E+03



An Online Neutron Detection System for Electron Storage Rings



Summary

- **Fission Detectors provide essential discrimination between photons and neutrons in a high gamma background**
- **With proper calibration, they can provide valuable information on photoneutron fluence within the accelerator tunnel**
- **They also monitor neutron doses in terms of neutron-induced damage of radiation sensitive equipment within the storage ring**

