



Radiation Characterization Measurements at the Advanced Photon Source

P. K. Job
Radiation Physicist
Advanced Photon Source

Radiation Characterization Measurements at the APS

10 CFR 835 (Subpart E)

Monitoring of individuals and areas shall be performed to ;


1. Demonstrate compliance with the regulations
2. Document radiological conditions
3. Detect changes in radiological conditions
4. Detect gradual buildup of radioactive material
5. Verify the effectiveness of engineering and process controls in reducing the radiation exposure.
6. Identify and control potential sources of individual exposure

Radiation Characterization Measurements at the APS Accelerators


- Measurement of Photon Dose with High Dose Dosimetry Techniques (Radiochromic Films)
- Measurement of Neutron Fluence online with good photon-neutron discrimination
- Measurement of Residual Activity of Accelerator Components
- MCNPX Calculations for Comparison




Measurement of Photon Dose in the Storage Ring (Radiochromic Films)



Measurement of Photon Dose in the Storage Ring (Radiochromic Films)



Measurement of Photon Dose in the Storage Ring (Radiochromic Films)




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Radiachromic Dosimetry Equipment




Radiation Physics Measurements at the APS




Pioneering
Science
and
Technology

Measurement of Photon Dose in the Storage Ring (Radiochromic Films)




Measurement of Photon Dose in the Storage Ring (Radiochromic Films)




Measurement of Photon Dose

Radiochromic Film Results



Measurement of Photon Dose


Radiochromic Film Results



Measurement of Photon Dose Radiochromic Film Results

Cumulative Insertion Device Dose

Run 1996-6 through Run 2002-3



Radiation Physics Measurements at the APS




Pioneering
Science
and
Technology


Measurement of Photon Dose

Radiochromic Film Results

Normalized Absorbed Dose Per Run for Sector 3
Downstream Insertion Device
(Device U27#12)



Measurement of Photon Dose Radiochromic Film Results



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology


Measurement of Photon Dose Summary

- Measurement of photon dose provides valuable information on the source term
- Dose at beamloss locations provide information on beam loss scenarios
- Radiation damage to the accelerator components can be correlated with the dose data
- Radiochromic films is a cost effective choice for high dose measurements in the storage ring




Measurement of Neutron Fluence in the Storage Ring

Electromagnetic Shower



Measurement of Neutron Fluence in the Storage Ring




Radiation Physics Measurements at the APS




Pioneering
Science
and
Technology


Measurement of Neutron Fluence in the Storage Ring



Measurement of Neutron Fluence in the Storage Ring (Neutron Yield)



Measurement of Neutron Fluence Photoneutron Spectra



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology


Neutron Fluence Measurements in the APS Storage Ring

- Require a detector with very high photon-neutron discrimination
- Require high neutron detection efficiency
 - ^{235}U Fission Detector
 - MOSFET Detectors
 - Bubble Detectors




Neutron Fluence Measurements in the Storage Ring

^{235}U Fission Detector



Typical Neutron-Induced Fission Reaction



Typical Fission Fragments
(~80 MeV each)

Fission Cross Section of Uranium Isotopes (^{235}U and ^{238}U)

Particle / Radiation	Energy	Cross Section (barns)	
		^{235}U	^{238}U
Thermal Neutrons	~ 25 meV	582 b	0.0 b
Fast Neutrons	$\sim 1\text{-}2$ MeV	1.2 b	0.6 b
Photons	>5.3 MeV	3-30 mb	3-30 mb

Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Neutron Fluence Measurements in the Storage Ring

^{235}U Fission Detector

Calibration of the Fission Detector with ^{252}Cf Neutron Source Spectrum

- Measure count-to-flux conversion factors for the detector-moderator configuration
- Optimize the moderator thickness to maximize efficiency



Calibration of the Fission Detector with ^{252}Cf Neutron Source Spectrum



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Calibration Results for Detector-Moderator Configuration

^{252}Cf Source – Gold Foil Activation Measurements

Source-Detector Distance (cm) (5 cm Sleeve)	Fluence rate from Au foil (n. $\text{cm}^{-2}.\text{s}^{-1}$)	Count rate (c.s $^{-1}$)	Conversion Factor ($\Phi/\text{c.s}^{-1}$)
30	9.4×10^{-5}	2.5×10^3	3.8×10^2
60	2.6×10^{-5}	7.1×10^2	3.7×10^2
100	1.3×10^{-5}	3.1×10^2	4.1×10^2
150	8.4×10^{-4}	1.7×10^2	4.9×10^2


Calibration Results for Detector-Moderator Configuration

Moderator Optimization (counts/s)

Distance from source	Bare detector	Detector with 3 cm poly.	Detector with 5 cm poly.	Detector with 7 cm poly.	Detector with 10 cm poly.
30 cm	13.6	1192	2510	3078	2428
60 cm	8.4	352	709	834	650
100 cm	7.0	161	302	345	271
150 cm	6.5	99	171	184	143



Neutron Detector Placement Inside the APS Storage Ring




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Neutron Count Rate vs. Lifetime




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Neutron Count Rate vs. Operating Mode



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology


Storage Ring Activation Measurements

- **Level of saturation activity during the run**
- **Activation elements at various locations**
- **Dose rates after the shut down and as a function of time**



Activation Measurements of Accelerator Components (3 ID Upstream Box)

3ID Upstream - Activation Analysis - December 27, 2001




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Activation Measurements of Accelerator Components (3 ID Downstream box)




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Activation Measurements of Accelerator Components (Booster Dump)



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Dose Measurements of Accelerator Components (3 ID Straight Section)

Sector 3 ID Vacuum Chamber


Date: 05/02/02

Time: 13:57

HP Tech: J.H. Vacca

Instr.: ASP-1 # 1833

Bckgrnd: <10 microR/h



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Dose Measurements of Accelerator Components (Booster Dump)

Date: 05/03/02


Time: 09:35

H.P.Tech: J. Vacca

Instr.: ASP-1 #1833

Bckgrnd: 10 microR/h

3.4 mR/h γ on contact
0.44 mR/h γ at 30 cm



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

Dose Measurements of Accelerator Components (Booster Dump)

Date: 05/14/02


Time: 14:31

H.P.Tech: J. Vacca

Instr.: ASP-1 #1833

Bckgrnd: 10 microR/h

2.6 mR/h γ on contact
0.32 mR/h γ at 30 cm



Dose Estimates due to Beam loss

MCNPX Simulation

MCNPX Monte Carlo Program for Photons and Neutrons

- Models the interactions of radiation/matter for 34 particles
 - Heavy ions are being added under NASA funding
- Uses both table and model physics
 - All standard and 150-MeV neutron, proton, photonuclear libraries
 - Photon, Electron physics (upto 1 GeV)
 - Bertini, ISABEL, CEM, INCL, and FLUKA
- 3-Dimensional, continuous energy, fully time-dependent
- Supported on all UNIX, PC Windows, Mac G5
 - Auto configuration, build system
 - FORTRAN90/95, dynamic allocation
 - Distributed memory parallel processing, PVM, MPI




Dose Estimates due to Beam loss (MCNPX Simulation)


- Dose Estimates due to Different Beamloss Scenarios at the Straight Section
- Estimates of Photon Dose
- Estimates of neutron Dose
- Comparison with the measurements



MCNP Simulation - Computational Geometry



MCNP Simulation - Computational Geometry




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

MCNP Simulation - Computational Geometry




Radiation Physics Measurements at the APS




Pioneering
Science
and
Technology


MCNP Simulation – Beamloss Scenario 1



MCNP Simulation – Beamloss Scenario 2



MCNP Simulation – Beamloss Scenario




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

MCNP Results for Photon Dose due to Beam Loss

Beam Loss = 10^{10} electrons




Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology

MCNP Results for Neutron Dose due to Beam Loss

Beam Loss = 10^{10} electrons



Radiation Physics Measurements at the APS



Pioneering
Science
and
Technology