## A-63

## Phase-contrast Imaging of Fatigue Crack Propagation through Grain Boundaries

Naji S. Husseini<sup>1</sup>, Clinique L. Brundidge<sup>2</sup>, Christopher J. Torbet<sup>3</sup>, Martina Zimmermann<sup>2</sup>, Alexander Deriy<sup>4</sup>, Wah-Keat Lee<sup>4</sup>, Tresa M. Pollock<sup>3</sup>, J. Wayne Jones<sup>2</sup>, and Roy Clarke<sup>1</sup>

Single-crystal nickel-base superalloys are used in critical aeronautic and power-generation applications where they undergo very high-cycle fatigue. They can have complicated dendritic microstructures and grain boundaries. The microstructure can drastically influence fatigue-crack growth, a dominant failure mode, affecting the growth rate and morphology. Synchrotron x-ray radiography is ideal for imaging crack growth in situ and in real time, and the spatial coherence allows phase-contrast imaging of the interfacial topology of minimally opened cracks. We installed a custom-built ultrasonic-fatigue instrument at sector 32-ID for stable fatigue-crack growth in thin, dogbone-shaped specimens. Samples were held with a mean tensile stress and cycled in tension at 20 kHz at R = -0.1. When crossing low-angle grain boundaries at large stress-intensity factors (K > ~7 MPa⋅m<sup>½</sup>), cracks remained on {111} planes without changing their growth rate appreciably. At lower K near the crack-initiation threshold, cracks followed grain boundaries by shifting among planes in the {111} family. At large-angle grain boundaries, cracks were arrested, requiring larger K to propagate further. After traversing the boundary, they would frequently continue to propagate intergranularly or non-crystallographically. These results are directly relevant to the behavior of superalloys under actual operating conditions.

<sup>&</sup>lt;sup>1</sup>Applied Physics Program, University of Michigan, Ann Arbor, MI 48109 <sup>2</sup>Department of Materials Science and Engineering, University of Michigan, Ann Arbor, MI 48109

<sup>&</sup>lt;sup>3</sup>Materials Department, University of California, Santa Barbara, CA 93106

<sup>&</sup>lt;sup>4</sup>X-ray Science Division, Argonne National Laboratory, Argonne, IL 60439